



Antidust tape set for SANUS greenhouses. Tear of 5cm of the protective layer from top and the bottom of the poycarbonate sheet. Put on top closing tape and on the bottom breathing tape. Every single polycarbonate sheet has to have tapes on before mounting on the greenhouse

