

Troubleshooting for Sidewall-screens for Pergola Gazebo

Roll-up not aligning correctly

If the Fabric/Roll-up function is aligned incorrectly – please make sure to fully extend the fabric all the way to the bottom of your pergola legs.

Fully extend the fabric until it stops. (Step 1)

Carefully hold onto the bottom bar of the fabric and bring it back up with even leveled force on both sides, see steps below. (Step 2)



Make sure to follow the fabric all the way up and do not let go until it is attached at the top.

This procedure requires a minimum of two people.

Fabric leaving guide-rail on

In case of wind, there is risk of the fabric leaving the guide-rails. Please make sure to not leave the sidewall pulled down.

If the fabric leaves the guide-rail, see steps below.

Firstly, bring the sidewall all the way up

Insert a flat screwdriver as the arrows display



This way, you will be able to go back to the Sidewall Manual and insert the fabric back into place.

This procedure requires a minimum of two people.