# DANCOVER®

Manual for Tentzing Explorer Family

(1,1+1,4+2,5)x3x2m

# DANCOVER®

## **Safety Advice**

#### **Attention**

In some countries approval is needed to set up a marquee/tent larger than 75 m2. It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof as heavy snow can cause the marquee/tent to collapse.

In the event of rain there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Maintenance: You must regularly check and retighten all assembly points of your storage shelter or garage tent. It is especially important to retighten the roof cover 1 month after having erected your shelter or tent. The roof cover of your shelter or tent must always be tensioned to withstand wind and weather.

#### **Warranty Information**

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.

#### **ASSEMBLY INSTRUCTIONS**

### Before you begin


Read all ins truction before set up.

- Select all level site clear of rocks, branches, and other hard or sharp objects, t o install your tent.
- **A**WARNING: Keep clear of overhead power lines.
- Do not set up your tent under trees because of potential lightning strikes or falling three limbs in inclement weather.
- Secure with <u>all</u> stakes and guylines provided to prevent property damage or personal injury.
- For best results in windy conditions, position narrow end of tent into the wind.
- Enlist the help of at least one other person to assist you when it is time to assemble the tent.

#### **Pole Descriptions**

Description	Qty.	
Main Body Pole (black, longest)	3	
Door Pole (red, long)	2	

Assemble all of the poles by interlocking shock-cored poles. Before setting-up the tent you should open the doors to get air into the tent, then close the doors - this will help you to sent - up the tent more easily. Push in the poles in their pole sleeves marked with matching colours. (Fig. 1) The tent can now be raised, for this you should be at least two persons. (Fig. 2)



PUSH IN THE POLES IN THEIR POLE SLEEVES MARKED WITH MATCHING COLOURS



THIS TENT SHOULD BE ERECTED BY AT LEAST 2 PERSONS

Place one end of the poles down over the metal pin fastened in the ring. (Fig. 3)
Go to the opposite end of the pole and apply pressure to the pole forming an arch until you are able to insert the other pole end over

the pin. Repeat this with the remaining poles. Clamp the hooks on the tent onto the poles. Repeat this with all poles.



"RING & PIN" SYSTEM FOR FASY SET UP

No w you are able to position the tent, as you require by pegging the fabric loops attached to the metal ring down. Start with the two end corners and then the two at the opposote end. Afterwards do it all way around the tent. Take one of the remaining red poles, insert it in the pole ring which is in the webbing placed in the hook f or connecting the thicker pole. (Fig. 4) Repeat for the other pole.



Finally secure the tent against strong winds with the preattached guylines and stakes. Use a mallet to secure the stakes. (Fig. 6)



FINALLY SECURE THE TENT AGAINST STRONG WIND

5

## **To Store**

- All poles and stakes must be placed in the storage bag to prevent damage to the fabric items places in the carry case.
- · Make sure tent is clean and dry before placing in carry case.
- · Remove rainfly, spread out on floor of tent, then unzip door & vents before taking tent down for storage.
- · Neatly fold tent to width of pole storage bag, place on tent, roll tightly, and place in carry case.
- · Store in a clean, dry area.

# **Things You Should Know:**

- Under certain conditions (cold weather, high humidity, etc.)
  condensation will form on the inside of your tent. Condensation
  is caused by water vapor from your breath, perspiration, or any
  wet clothing inside the tent. It is NOT LEAKAGE through the tent
  fabric. It can be minimized by removing wet clothing from your
  tent and by providing good ventilation through the tent.
- Tree limbs, tree sap, bird droppings, or moisture steadily dripping off tree limbs can cause damage to the tent fabric and its coating resulting in leaks.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use a separate storage bag.
- Stake should be removed by pulling on the stake itself.
   NEVER PULL ON THE TENT TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.
- Tent poles should not be left telescoped together during storage.
- Do not leave your tent set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.

▲WARNING: Keep all flame and heat sources away from this tent fabric.

# DANCOVER®

# Contact information

Head office:

Dancover A/S Nordre Strandvej 119 G 3150 Hellebæk Denmark For more information please visit: www.dancovershop.com

#### National contact

Denmark:

denmark@dancover.com

UK:

uk@dancover.com

Germany:

germany@dancover.com

France:

france@dancover.com

Sweden:

sverige@dancover.com

Finland:

suomi@dancover.com

Poland:

polska@dancover.com

Luxembourg:

luxembourg@dancover.com

Spain:

espana@dancover.com

Italy:

italia@dancover.com

Switzerland:

schweiz@dancover.com

Austria:

austria@dancover.com

Norway:

norge@dancover.com

Nederland:

nederland@dancover.com

Ireland:

ireland@dancover.com

Belgium:

belgique@dancover.com