# DANCOVER®

Party tent 6 m PVC Series

#### **Safety Advice**

#### **Attention**

In some countries approval is needed to set up a tent larger than 75 m2.

The owner of the tent has the sole responsibility to make sure that these local rules are followed and that the mounting is correct.

In case of bad weather conditions, it is your responsibility to ensure that people inside are safe and that the tent does not cause damage to others.

Do not use open fire, welding equipment or other ignition sources in the tent. Though the fabric is made of flame retardant material it can still burn.

It is always recommended that you secure your tent properly with safety straps and augers when you put up the structure.

We recommend you to insure the tent, or check if it is covered by home contents insurance, in case of unplanned events, accidents or bad weather.

Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.


This structure is not tested for specific snow and wind loads. That's why we always recommend to remove snow from the top.

| Part list. |        |        |        |        |        |        |  |  |  |  |
|------------|--------|--------|--------|--------|--------|--------|--|--|--|--|
| Part No.   | Part   | 6m     | 8m     | 10m    | 12m    | 14m    |  |  |  |  |
| No. 01     | 1470mm | 16 PCS | 20 PCS | 24 PCS | 28 PCS | 32 PCS |  |  |  |  |
| No. 02     | 1940mm | 27 PCS | 34 PCS | 41 PCS | 48 PCS | 55 PCS |  |  |  |  |
| No. 03     |        | 8 PCS  | 10 PCS | 12 PCS | 14 PCS | 16 PCS |  |  |  |  |
| No. 04     |        | 8 PCS  | 10 PCS | 12 PCS | 14 PCS | 16 PCS |  |  |  |  |
| No. 05     |        | 4 PCS  | 5 PCS  | 6 PCS  | 7 PCS  | 8 PCS  |  |  |  |  |
| No. 06     | 5 6    | 4 PCS  |  |  |  |  |
| No. 07     |        | 4 PCS  | 6 PCS  | 8 PCS  | 10 PCS | 12 PCS |  |  |  |  |
| No. 08     | 8 8    | 2 PCS  |  |  |  |  |
| No. 09     | 388    | 2 PCS  | 3 PCS  | 4 PCS  | 5 PCS  | 6 PCS  |  |  |  |  |
| No. 10     | 8      | 4 PCS  | 6 PCS  | 8 PCS  | 10 PCS | 12 PCS |  |  |  |  |
| No. 11     | 8      | 4 PCS  |  |  |  |  |
| No. 12     |        | 4 PCS  |  |  |  |  |
| No. 13     | 3 3    | 4 PCS  | 6 PCS  | 8 PCS  | 10 PCS | 12 PCS |  |  |  |  |


| Part list. |            |         |         |         |         |         |  |  |  |  |
|------------|------------|---------|---------|---------|---------|---------|--|--|--|--|
| Part No.   | Part       | 6m      | 8m      | 10m     | 12m     | 14m     |  |  |  |  |
| No. 14     |            | 4 PCS   |  |  |  |  |
| No. 15     | d          | 4 PCS   |  |  |  |  |
| No. 16     | R          | 8 PCS   | 10 PCS  | 12 PCS  | 14 PCS  | 16 PCS  |  |  |  |  |
| No. 17     | 145        | 36 PCS  | 42 PCS  | 48 PCS  | 54 PCS  | 60 PCS  |  |  |  |  |
| No. 18     | ر<br>ا     | 122 PCS | 152 PCS | 182 PCS | 212 PCS | 242 PCS |  |  |  |  |
| No. 19     | -0-        | 16 PCS  | 20 PCS  | 24 PCS  | 28 PCS  | 32 PCS  |  |  |  |  |
| No. 20     | 000        | 112PCS  | 132PCS  | 152 PCS | 172PCS  | 192 PCS |  |  |  |  |
| No. 21     | 0          | 26 PCS  |  |  |  |  |
| No. 22     |            | 4 PCS   |  |  |  |  |
| Ch         | S 14 17 18 |         | SA T    |         |         |         |  |  |  |  |
| No. 24     | ESECSEL.   | 1 PCS   |  |  |  |  |
| No. 25     |            | 6 PCS   | 8 PCS   | 10 PCS  | 12 PCS  | 14 PCS  |  |  |  |  |
| No. 26     |            | 2 PCS   |  |  |  |  |

## Assembly


- **Step 1:** Lay out all roof tubes and connectors as shown.
- **Step 2:** Join the roof tubes and connectors from middle and out.



- **Step 3:** Apply the gable safety bars as shown.
- **Step 4:** Make sure all screws are tightened.




- **Step 5:** Apply legs in one side as shown.
- **Step 6:** Put the roof cover on and tie down with bungeeballs as shown.
- \* Note, tie in the bungee-balls 5 at one side followed by 5 in the other and continue until finished



- Step 7: Raise the legs in the opposite site.
- Step 8: Make sure the cover is fastened.




- **Step 9:** Lay out the conectors and tubes of the Ground Bar.
- Step 10: Assemble Ground Bar as shown.




## Assembly


- **Step 11:** Attach sidewalls with Bungeeballs as shown.
- **Step 12:** Connect leg cover with sidewall and endwall by velcro as shown



- **Step 13:** Attach endwalls with Bungee balls as shown.
- Step 14: Connect leg cover with sidewall and endwall by velcro as shown



## Roof Assembly




Step 1: Lay out all roof tubes and connectors as shown above.

Step 2: Join the roof tubes and connectors from middle and out.

#### DANCOVER®

### Gable Assembly




Step 3: Apply the gable safety bars as shown above.

Step 4: Make sure all screws are tightened.

DANGOVER

ANCOVER

## Ground Bar Assembly



Step 9: Lay out the conectors and tubes of the ground bar.

Step 10: Assemble ground bar as shown above.

, ANG

ANC'

## DANCOVER®

#### Contact information

Head office:

Dancover A/S Nordre Strandvej 119 G 3150 Hellebæk Denmark For more information please visit: www.dancovershop.com

#### National contact

Denmark:

denmark@dancover.com

UK:

uk@dancover.com

Germany:

germany@dancover.com

France:

france@dancover.com

Sweden:

sverige@dancover.com

Finland:

suomi@dancover.com

Poland:

polska@dancover.com

Luxembourg:

luxembourg@dancover.com

Spain:

espana@dancover.com

Italy:

italia@dancover.com

Switzerland:

schweiz@dancover.com

Austria:

austria@dancover.com

Norway:

norge@dancover.com

Nederland:

nederland@dancover.com

Ireland:

ireland@dancover.com

Belgium:

belgique@dancover.com