

PARTY TENT SEMI PRO, CombiTent

6m series

DANCOVER[®]

Safety Advice

Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m2. It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions. In the event of snow always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof as heavy snow can cause the marquee/tent to collapse.

In the event of rain there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

Warranty Information

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Pipe 50-50		1	16	20	24	28	32
Pipe 38-38	0	2	23	30	37	44	51
		3-1	2	2	2	2	2
Pipe 38-38 with hole	0	3-2	2	2	2	2	2
Pipe roof brace 6-series horizental	(o o)	4	8	10	12	14	16
Pipe roof brace 6-series horizental	(°(°)	5	4	5	6	7	8
Pipe 25-25 diagonal pipe	0	6	4	4	4	4	4
Pipe 50-50 with holes	() 0000)	7	4	6	8	10	12
Pipe 50-50 with holes and a hole	() o ooo)	8	4	4	4	4	4
connector Three way 110 °54-42		10	4	4	4	4	4

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
connector Three way 140 °54-42		11	2	2	2	2	2
connector four way 140 °54-42		12	2	3	4	5	6
connector four way 110 °54-42		13	4	6	8	10	12
Cross piece 54-42		14	4	6	8	10	12
T-piece 54-42		15	4	4	4	4	4
Connector three way –foot for the corners 54-42	°	16	2	2	2	2	2


Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Connector three way –foot for the corners 54-42		17	2	2	2	2	2
Connector three way –foot for the sidewalls 54-42		18	4	6	8	10	12
Connector three way –foot for the endwalls 54-42		19	4	4	4	4	4
Groundpegs		20	4	6	8	10	10
Screw hook	2-0	21	4	4	4	4	4
Groundpeg 6x180mm		22	8	10	12	14	16


Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
Groundpeg 4x180mm		23	36	42	48	54	60
Screw M8X50mm	S.	24	58	72	86	100	114
Screw M8X60mm	J.	25	52	64	76	88	100
Locknuts M8	Ø	26	110	136	162	188	214
Wing nut M6	P	29	16	20	24	28	32
Screw M6X25mm	ST -	30	16	20	24	28	32

Dimension		Part No.	6x6	6x8	6x10	6x12	6x14
spanner		31	2	2	2	2	2
Long bungeeball	\mathcal{O}	33	112	132	152	172	192
Short bungeeball	δ	34	26	26	26	26	26
rope		35	4	4	4	4	4
roof	THE REAL	37	1	1 (3 sections)	1	1 (4 sections)	1 (5 sections)
sidewall		38	6	8	10	12	14


Dimension	Part No.	6x6	6x8	6x10	6x12	6x14
endwall with large door	39	1	1	1	1	1
endwall with small door	40	1	1	1	1	1

13-08-2014-SH





III Lift one side of the tent frame and attach the legs(7).Attach the legs with part no. 8 to the outside in all four corners. Place the roof onto the frame and use the bungees to fasten it .Be sure not to put too much tension on the bungees in order not to make attaching the other side more difficult.	
IV Attach the legs on the other side and install the feet(16,17,18,19)at the bottom.Use the long ground pegs to fasten the feet to the ground.Attached the side covers to the pipes(7,8) Connect leg cover with sidewall and endwall by velcro as shown. Reinforce the side frame by attaching the diagonmal pipes(6) to all four corners .Complete the bottom frame with the required pipes(2) and connectors(16,17,18,19).	middle peg 2 2 19 18 2 2 16 6 5 5 5 5 5 5 5 5 5 5 5 5 5





Contact information					
Head office:					
Dancover A/S Nordre Strandvej 119 G 3150 Hellebæk Denmark	For more information please visit: www.dancovershop.com				
National contacts					
Denmark: 70 26 76 20	Spain: 911 436 828				
denmark@dancover.com	espana@dancover.com				
UK: 020 8099 7570	Italy: 02 479 21 198				
uk@dancover.com	italia@dancover.com				
Germany: 041 0266 7040	Switzerland: 0840 000125				
germany@dancover.com	schweiz@dancover.com				
France: 0975 181 800	Austria: 0662 626935				
france@dancover.com	austria@dancover.com				
Sweden: 040 233 262	Norway: 231 00 690				
sverige@dancover.com	norge@dancover.com				
Finland: 0 931 581 720	Nederland: 0 858 880 524				
suomi@dancover.com	nederland@dancover.com				
Poland: 22 300 8602	Ireland: 0 151 33 003				
polska@dancover.com	ireland@dancover.com				
Luxembourg: +49 041 0266 7040	Belgium: 0 28 08 08 09				
luxembourg@dancover.com	belgique@dancover.com				
Portugal: 308 800 899 portugal@dancover.com					