DANCOVER®

Manual for Pagoda Marquee UNICO 4x4m

DANCOVER®

Safety Advice

Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m2. It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof as heavy snow can cause the marquee/tent to collapse.

In the event of rain there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

Warranty Information

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.

4x4m UNICO Pagoda INSTRUCTION		
Part no.	Reference image	4x4m
1		1
2		4
3		4
4		4
5		8
6		4
7		4
8		2
9		4
10		4
11		16


13		1
14	3-0	4
15		4
16		32
17		48
18		48
19		76
20		4
21		1
22		6
23		2

Assemble Manual

STEP 1


Select a flat ground for the tent, unpack the carton and check all the parts including tubes, tent and accessories... etc. are present as same as list.

Assemble the framework of rooftop by joining the portion (6.7) together with poles (11). To ensure the screw fixed to every pole tightly.




STEP 2

Complete the roof structure. Strengthen the whole roof structure by steel wires (8.13).




STEP 3

Cover the roof on the frame, and attach it by the bungee balls properly, take care of the tension of the bungee balls, for if you use too many on one side of tent, it may too tight to tie the other side of it.




STEP 4

Attached all legs in to the connector, and finish the groundframe to the structure.



STEP 5

Hang all the sidewalls. Connect the leg covers to the sidewalls and endwalls with velcro as shown.



Warning:

- 1. In order to avoid being rusted by air, oil is covered on the surface of the pipes, before set up the tent, please remove the oil carefully first to keep the cover clean.
- 2. Take note that the tent needs to be handled carefully to avoid admage.
- 3. Do not force the frame as they may be damage in the process.
- 4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.
- 5. The windows maybe a little bit sticky to each other, when you unfold the windows, please do as softly as you can. Or the windows maybe crack during the process.

Please select a suitable site for the tent to avoid the damage to underground sprinkler systems, water, gas or electrical lines.

DANCOVER®

Contact information

Head office:

Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Denmark

For more information please visit: www.dancovershop.com

National contact

Denmark: 70 26 76 20 denmark@dancover.com

UK: 020 8099 7570 uk@dancover.com

Germany: 041 0266 7040 germany@dancover.com

France: 0975 181 800 france@dancover.com

Sweden: 040 233 262 sverige@dancover.com

Finland: 0 931 581 720 suomi@dancover.com

Poland: 22 300 8602 polska@dancover.com

Luxembourg: +49 041 0266 7040

luxembourg@dancover.com

Portugal: 308 800 899 portugal@dancover.com

Spain: 911 436 828

espana@dancover.com

Italy: 02 479 21 198 italia@dancover.com

Switzerland: 0840 000125 schweiz@dancover.com

Austria: 0662 626935 austria@dancover.com

Norway: 231 00 690 norge@dancover.com

Nederland: 0 858 880 524 nederland@dancover.com

Ireland: 0 151 33 003 ireland@dancover.com

Belgium: 0 28 08 08 09 belgique@dancover.com